fitting comfort and ease into daily life



AFTER DRESSING USERS: SHARI



A STICK USER, SHARI GETS
COMPLETELY DRESSED
BEFORE APPLYING UAP.
SHE DOES THIS BECAUSE SHE
DOES NOT WANT WHITE
MARKS ON CLOTHES.
HERE SHE CONTORTS HER
WRIST AND STRETCHES
OUT SWEATER IN ORDER
TO APPLY.

AFTER DRESSING USERS: KLARA



ANOTHER STICK USER, KLARA
ADJUSTS HER ROUTINE
BASED ON WHAT SHE'S
WEARING.

IF SHE'S WEARING A TIGHTER SHIRT, LIKE A TANK TOP,

SHE'LL PUT UAP ON AFTER DRESSING.

SHE DOES THIS **TO AVOID**WHITE MARKS.

KLARA IS ALSO A USER WHO

REAPPLIES DURING THE DAY.

UNDER CLOTHES APPLICATION EXPLAINED

WHY DO USERS APPLY WITH THEIR CLOTHES ON?

- THEY ARE **CONCERNED ABOUT WHITE MARKS** ON THEIR CLOTHING
- UAP USERS FORGET TO APPLY
- THEY NEED TO REAPPLY UAP DURING THE DAY

UNDER CLOTHES APPLICATION EXPLAINED

WHAT ARE THE CHALLENGES WHILE APPLYING?

- UAP USERS ARE **STRUGGLING WITH A LIMITED SPACE**AND **WITH LIMITED VISIBILITY.**
- THEY STRAIN THEIR NECK AND WRIST TO REACH THEIR ARMPITS
- BEING CAREFUL TO AVOID WHITE MARKS, THEY MAY STRETCH
 OUT CLOTHING

HOW CAN UNDER CLOTHES UAP APPLICATION BE IMPROVED?

CONTROL: USERS SHOULD BE ABLE TO GRIP AND MANEUVER THE UAP CONTAINER WHILE EXPERIENCING

LIMITED SPACE AND VISIBILITY

HOW CAN UNDER CLOTHES UAP APPLICATION BE IMPROVED?

CONTROL: USERS SHOULD BE ABLE TO **GRIP** AND MANEUVER

THE UAP CONTAINER WHILE EXPERIENCING

LIMITED SPACE AND VISIBILITY

COMFORT: USERS SHOULD BE ABLE TO **REACH** UNDER THEIR

CLOTHING WITHOUT STRAIN

HOW CAN UNDER CLOTHES UAP APPLICATION BE IMPROVED?

CONTROL: USERS SHOULD BE ABLE TO **GRIP** AND MANEUVER

THE UAP CONTAINER WHILE EXPERIENCING

LIMITED SPACE AND VISIBILITY

COMFORT: USERS SHOULD BE ABLE TO **REACH** UNDER THEIR

CLOTHING WITHOUT STRAIN

EASE: USERS SHOULD BE ABLE TO APPLY UAP WITHOUT

WORRYING THAT IT MIGHT TOUCH THEIR

CLOTHING

MY INVESTIGATION INCLUDED:

• RESEARCH OF THE GRIP PRODUCT LANDSCAPE

MY INVESTIGATION INCLUDED:

• RESEARCH OF THE GRIP PRODUCT LANDSCAPE

USER TESTING OF ERGONOMICS

MY INVESTIGATION INCLUDED:

RESEARCH OF THE GRIP PRODUCT LANDSCAPE

USER TESTING OF ERGONOMICS

USER TESTING OF PRODUCT
 ADVANCERS

MY INVESTIGATION INCLUDED:

RESEARCH OF THE GRIP PRODUCT LANDSCAPE

USER TESTING OF ERGONOMICS


USER TESTING OF PRODUCT ADVANCERS

MY GOAL WAS TO FIND A UAP THAT UTILIZES


CONTROL, COMFORT AND EASE WHILE APPLYING IN
A LIMITED SIGHT SITUATION THAT AVOIDS WHITE
MARKS ON CLOTHING.

GRIP PRODUCT LANDSCAPE


ONE-HANDED
TOOLS USED IN
RESTRICTED SPACE




INVESTIGATION OF CONTROL: GRIP PRODUCT LANDSCAPE



INVESTIGATION OF CONTROL: GRIP PRODUCT LANDSCAPE



INVESTIGATION OF CONTROL: GRIP PRODUCT LANDSCAPE




ERGONOMICS


COMFORT AND FORM
TESTED BY USERS




INVESTIGATION OF ERGONOMICS: FORM STUDY



INVESTIGATION OF ERGONOMICS: FORM STUDY



INVESTIGATION OF ERGONOMICS: FORM STUDY



EACH SHAPE WAS TESTED BY 5 USERS IN FOUR STAGES:

COMFORT IN HAND. USERS DID NOT KNOW INTENDED USE OF FORM.

AND THREE CONDITIONS OF UAP APPLICATION:



INTRODUCTION TO USER TESTERS




ESIN



NICOLE



SAHAR







KATHLEEN

INVESTIGATION OF ERGONOMICS: COMFORT IN HAND

ROUNDER, SOFTER, CURVED FORMS WERE PREFERRED.












USERS HAVE **DIFFERENT WAYS OF APPLYING IN DIFFERENT SITUATIONS.**

NICOLE'S METHOD
IS ONE-HANDED
WHEN UNRESTRICTED BY
CLOTHING





WEARING
A JACKET
CHANGES
HER PROCESS



SHAPE OF THE UAP MAY ALSO AFFECT APPLICATION



BEING ABLE TO REACH THE ARMPIT IN SITUATIONS WHEN SPACE IS LIMITED IS IMPORTANT. A LONGER FORM MAY HELP.








KATHLEEN ADMITS THAT THE LONG,
NARROW SHAPE LETS HER REACH
HER ARMPIT MORE EASILY.

THE USER'S BODY MUST CONTORT IN ORDER TO APPLY IN DIFFER-ENT CLOTHING SITUATIONS.









NICOLE'S BODY BECOMES **MORE AWKWARD** THE **MORE CLOTHING SHE WEARS** AND THE **SMALLER THE SPACE BECOMES BETWEEN HER ARMPIT AND HER CLOTHING.**

UAP CAN GET CAUGHT ON CLOTHING.



HERE, A **FLAT EDGE GETS CAUGHT** ON ROWEN'S SHIRT.



A **ROUND SIDE EDGE GLIDES OVER** ROWEN'S SHIRT.

DIFFERENT FORMS ARE SUCCESSFUL FOR **DIFFERENT SITUATIONS.**





SAHAR PREFERS ROUNDER, MORE COMPACT FORMS WHEN SHE'S WEARING A TANK TOP AND LONGER FORMS TO OFFER MORE CONTROL WHEN SHE'S WEARING LAYERS OF CLOTHING.

INVESTIGATION OF ERGONOMICS: RESULTS

SOAP	SOAP	SOAP	GRIP	SOAP
STICK	EGG	HANDLE	GRIP	HANDLE
HANDLE	EGG	GRIP	STICK	HANDLE

INVESTIGATION OF ERGONOMICS: TESTING SUMMARY

- BEST COMFORT IN HAND
- BEST **T-SHIRT** APPLICATION
- FITS IN THE PALM AND ARMPIT


SOAP

INVESTIGATION OF ERGONOMICS: TESTING SUMMARY

- BEST COMFORT IN HAND,
- BEST T-SHIRT APPLICATION
- FITS IN THE PALM AND ARMPIT



- CONTROL
- **REACH** INTO TIGHT SPACES



INVESTIGATION OF ERGONOMICS: TESTING SUMMARY



A SUCCESSFUL UNDER CLOTHES UAP APPLICATION SHAPE HAS:

- A **SOFT CURVE** FOR **COMFORT**
- A LONGER FORM FOR REACHING ABILITIES.

PRODUCT ADVANCERS

EASE OF MOVEMENT UNDER CLOTHES TESTED BY USERS



INVESTIGATION OF PRODUCT ADVANCERS

FIVE ADVANCING MECHANISMS WERE PROTOTYPED TO:

- EXPOSE THE PRODUCT WHILE UNDER THE CLOTHES
- MINIMIZE WHITE MARKS
- REACH THE ARMPIT.



INVESTIGATION OF PRODUCT ADVANCERS: ONE

DIAL





- A **VERTICAL ROLLING DIAL** REPLACES THE HORIZONTAL DIAL
- PRODUCT MOVES UP ACCORDING TO HEIGHT PREFERENCE OF USER.

INVESTIGATION OF PRODUCT ADVANCERS: DIAL



INVESTIGATION OF PRODUCT ADVANCERS: TWO

SLIDER





- A **SLIDING BUTTON** ON THE FRONT
- PRODUCT MOVES UP AND DOWN AS FAR AS USER NEEDS IT.

INVESTIGATION OF PRODUCT ADVANCERS: SLIDER





POSITIVES:

- ACCESSIBLE
- •GOOD FOR ONE HAND APPLICATION

NEGATIVES:

- HARD TO KNOW HOW HIGH IS
- MAY DIAL BEFOREHAND

INVESTIGATION OF PRODUCT ADVANCERS: THREE


SQUEEZE





- A **FLEXIBLE BUTTON** PRESSES INTO THE CONTAINER TO MOVE PRODUCT
- TACTILE, ONE MOTION

INVESTIGATION OF PRODUCT ADVANCERS: SQUEEZE



- MOLDS IN HAND
- DIFFERENT, YET SUBTLE
- DON'T HAVE TO SEE IT
- DOESN'T FEEL LIKE HARD PLASTIC



INVESTIGATION OF PRODUCT ADVANCERS: FOUR

PUMP





- A **LEVER IS HELD** TO MOVE PRODUCT
- ONE MOTION

INVESTIGATION OF PRODUCT ADVANCERS: PUMP





POSITIVES:

- HOLDS PRODUCT IN ONE PLACE
- FUN, INTERESTING: NEW WAY OF USE
- OPPORTUNITIES FOR NEW FORM

NEGATIVES:

- FEELS UNSTABLE
- STANDING ISSUES
- MAY BE HARDER IN OTHER HAND
- MAY GET DEPRESSED IN BAG

INVESTIGATION OF PRODUCT ADVANCERS: FIVE

STAMP



INVESTIGATION OF PRODUCT ADVANCERS: STAMP






POSITIVES:

- NO INTERUPTION WITH FORM
- UNDER SURFACE UNTIL READY
- GUARD WOULD KEEP UAP OFF OF CLOTHES
- ONE MOTION


NEGATIVES:

- EDGE MIGHT SCRAPE
- WANT TO RUB PRODUCT


INVESTIGATION OF EASE: RESULTS




INVESTIGATION OF EASE: RESULTS




RECOMMENDATION FROM TESTING AND RESEARCH



RECOMMENDATION FROM TESTING AND RESEARCH



RECOMMENDATION FROM TESTING AND RESEARCH















SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010



SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010



SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010



SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010



SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010

close: comfort and ease



SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010

close: comfort and ease



SARA DIERCK/COLGATE PALMOLIVE/GARY NATSUME/UAP/SPRING 2010



close: in store environment



close: in your home



